

General VEC IN-USB-1 Installation Support

Download and install your transcription software. Reboot computer. Plug the **VEC IN-USB-1** foot pedal into an available USB port on your computer. Windows should immediately report that New Hardware has been found. On Windows 2000 or XP, Windows will automatically add the appropriate drivers. However, in some instances a driver maybe needed to be downloaded and installed from your transcription programs website.

Installing the VEC IN-USB-1 Foot Pedal on Windows XP:

Plug the **VEC IN-USB-1** foot pedal directly into an open USB port on your PC. The foot pedal will be recognized automatically as long as your PC has full USB support.

General Installation Information:

- Download and install transcription software
- Reboot computer
- Plug in the VEC IN-USB-1 foot pedal to an available USB port on your computer.
- If computer does not recognize foot pedal try another available USB port.

Installing the VEC IN-USB-1 on Windows 98:

The Add New Hardware window will prompt you to install the drivers for the new device. Choose "Search for the best driver for your device." Windows will now ask you where to search for the device drivers. Choose "CD-ROM drive" and insert the Windows 98 CD into the computer's CD-ROM drive. Then click "Next". Follow instructions on screen. Support for the USB device should now be installed.

Note: USB is not supported by Windows NT or by most releases of Windows 95. USB ports on PCs that are more than 4 years old may be of too low a voltage to recognize an un-powered device like a foot pedal.